


End Plates for ST 5/XH, ST 5/H



- The protective covers and end plates are provided in working areas to increase safety
 - They can be ordered separately for conveyor units; for curves, diverters, and junctions they are optionally included in the scope of delivery (SC = 2)
 - The protective covers and end plates are clipped between the rollers using spring elements
 - **Note:** Do not walk on the protective covers or end plates
-
- Protective covers for various widths and roller spacings
 - Special covers for conveyor section center, transitions, and ends
 - **End plates**
 - End plate, left drive side (**D**)
 - End plate, right drive side (**E**)
 - Lateral guide cover
 - Lateral guide protective cover (**F**), 2x required
 - **Thread forming screw**
 - Screw (**G**), 4 required for each end plate (**D/E**) and 2 for each lateral guide cover (**F**)
-
- Spring element
 - Spring element (**H**), 2x required for each end plate
 - Caps
 - cover cap for the open profile ends (**J**), 2x required for each section end


Product description

Conveyor unit selection

Technical data

No.	Material
3842545679	Galvanized steel
3842545680	
3842545681	
3842545682	
3842545683	
3842545684	
3842545685	
3842545686	
3842545687	
3842545476	
3842545477	
3842545688	
3842545689	
3842545690	
3842545691	
3842545692	
3842545693	
3842545694	
3842545695	
3842545696	
3842545697	
3842545474	
3842545475	
3842545698	
3842545276	
3842563978	
3842545214	
3842548757	PP
3842548795	

Ordering codes



	b ¹⁾	p ²⁾		ESD	No.
	mm	mm			
ST5/XH, ST5/H end plate; AS on left 455/130	455	130			3842545679
ST5/XH, ST5/H end plate; AS on left 455/195	455	195			3842545680
ST5/XH, ST5/H end plate; AS on left 650/130	650	130			3842545681
ST5/XH, ST5/H end plate; AS on left 650/195	650	195			3842545682
ST5/XH, ST5/H end plate; AS on left 650/260	650	260			3842545683
ST5/XH, ST5/H end plate; AS on left 845/130	845	130			3842545684
ST5/XH, ST5/H end plate; AS on left 845/195	845	195			3842545685
ST5/XH, ST5/H end plate; AS on left 845/260	845	260			3842545686
ST5/XH, ST5/H end plate; AS on left 845/325	845	325			3842545687
ST5/XH, ST5/H end plate; AS on left 1040/130	1040	130			3842545476
ST5/XH, ST5/H end plate; AS on left 1040/195	1040	195			3842545477
ST5/XH, ST5/H end plate; AS on left 1040/260	1040	260			3842545688
ST5/XH, ST5/H end plate; AS on right 455/130	455	130			3842545689
ST5/XH, ST5/H end plate; AS on right 455/195	455	195			3842545690
ST5/XH, ST5/H end plate; AS on right 650/130	650	130			3842545691
ST5/XH, ST5/H end plate; AS on right 650/195	650	195			3842545692
ST5/XH, ST5/H end plate; AS on right 650/260	650	260			3842545693
ST5/XH, ST5/H end plate; AS on right 845/130	845	130			3842545694
ST5/XH, ST5/H end plate; AS on right 845/195	845	195			3842545695
ST5/XH, ST5/H end plate; AS on right 845/260	845	260			3842545696
ST5/XH, ST5/H end plate; AS on right 845/325	845	325			3842545697
ST5/XH, ST5/H end plate; AS on right 1040/130	1040	130			3842545474
ST5/XH, ST5/H end plate; AS on right 1040/195	1040	195			3842545475

	b ¹⁾	p ²⁾		ESD	No.
	mm	mm			
ST5/XH, ST5/H end plate; AS on right 1040/260	1040	260			3842545698
Lateral guide cover			2		3842545276
Thread forming screws for end plates			100		3842563978
Spring element			50		3842545214
Cover cap 45x90, black			20		3842548757
Cover cap 45x180, black			20		3842548795

1) b = track width

2) p = roller spacing