

Schalterhalter in HQ 2/...
 Switch bracket in HQ 2/...
 HQ 2/... 中的开关支架
 Support d'interrupteur dans HQ 2/...
 Portainterruttore in HQ 2/...
 Portainterruptor en HQ 2/...
 Suporte de interruptor em HQ 2/...

3 842 559 979/2018-12
 Replaces: –
 DE+EN+ZH+FR+IT+ES+PT




Montageanleitung • Assembly instructions • 安装说明书 • Instructions de montage
 Istruzioni per il montaggio • Instrucciones de montaje • Instruções de montagem

3 842 559 609
3 842 559 610
3 842 559 611
3 842 559 612


HQ 2/U,
 $b_L \geq 240 \text{ mm}$
 2
HQ 2/U,
 $b_L = 160 \text{ mm}$
 3

3 842 559 612




HQ 2/U2
 4
HQ 2/O, .../T,
BG II
 10

3 842 559 609




HQ 2/U-H,
 $b_L = 240 \text{ mm}$
 5
HQ 2/U-H,
 $b_L \geq 320 \text{ mm}$
 6

3 842 559 611




HQ 2/O, .../T,
 $b_L = 160 \text{ mm}$
 7
HQ 2/O, .../T,
 $b_L \geq 240 \text{ mm}$
 8, ... 9

3 842 559 608



EQ 2/TR-90,
 $b_L = 160 \text{ mm}$
 11

3 842 559 610



HQ 2/U, $b_L \geq 240$ mm

1) 3 842 549 814

Kein Lieferumfang!

Not included in the scope of delivery!

不在供货范围内!

Pas compris dans la fourniture !

Non compreso nella fornitura!

No incluido en el volumen de suministro.

Não incluído no lote de fornecimento!

2) Vorhandenes Bauteil aus HQ 2/... wieder verwenden.

Reuse existing component from HQ 2/...

重复使用 HQ 2/... 中的现有部件。

Réutiliser le composant disponible de HQ 2/...

Utilizzare nuovamente il componente disponibile da HQ 2/...

Volver a utilizar el componente HQ 2/... existente.



Utilizzare nuovamente il componente disponibile da HQ 2/...

Volver a utilizar el componente HQ 2/... existente.

Voltar a utilizar a peça existente do HQ 2/...

Voltar a utilizar a peça existente do HQ 2/...

3 842 559 612



HQ 2/U, $b_L = 160$ mm

1) 3 842 549 814

Kein Lieferumfang!

Not included in the scope of delivery!

不在供货范围内!

Pas compris dans la fourniture !

Non compreso nella fornitura!

No incluido en el volumen de suministro.

Não incluído no lote de fornecimento!

2) Vorhandenes Bauteil aus HQ 2/... wieder verwenden.

Reuse existing component from HQ 2/...

重复使用 HQ 2/... 中的现有部件。






Réutiliser le composant disponible de HQ 2/...

Utilizzare nuovamente il componente disponibile da HQ 2/...




Volver a utilizar el componente HQ 2/... existente.

Voltar a utilizar a peça existente do HQ 2/...

3 842 559 612



M8x40



$M_D = 10$ Nm



$M_D = 25$ Nm



$M_D = 10$ Nm



$M_D = 25$ Nm



$M_D = 5$ Nm



$M_D = 1$ Nm

HQ 2/U2

1) 3 842 549 814

Kein Lieferumfang!

Not included in the scope of delivery!

不在供货范围内!



Pas compris dans la fourniture !

Non compreso nella fornitura!

No incluido en el volumen de suministro.

Não incluído no lote de fornecimento!

3 842 559 609



HQ 2/U-H, $b_L = 240 \text{ mm}$

1) 3 842 549 814

Kein Lieferumfang!

Not included in the scope of delivery!

不在供货范围内!



Pas compris dans la fourniture !

Non compreso nella fornitura!

No incluido en el volumen de suministro.

Não incluído no lote de fornecimento!

3 842 559 611



HQ 2/U-H, $b_L \geq 320$ mm

1) 3 842 549 814

Kein Lieferumfang!

Not included in the scope of delivery!

不在供货范围内!



Pas compris dans la fourniture !

Non compreso nella fornitura!

No incluido en el volumen de suministro.

Não incluído no lote de fornecimento!

3 842 559 611



HQ 2/O, .../T, b_L = 160 mm

1) 3 842 549 814

Kein Lieferumfang!

Not included in the scope of delivery!

不在供货范围内!

Pas compris dans la fourniture !

Non compreso nella fornitura!

No incluido en el volumen de suministro.

Não incluído no lote de fornecimento!

2) Vorhandenes Bauteil aus HQ 2/... wieder verwenden.

Reuse existing component from HQ 2/...

重复使用 HQ 2/... 中的现有部件。


Réutiliser le composant disponible de HQ 2/...

Utilizzare nuovamente il componente disponibile da HQ 2/...



Volver a utilizar el componente HQ 2/... existente.

Voltar a utilizar a peça existente do HQ 2/...

3 842 559 608




M8x30 bei b_Q=160
M8x40 bei b_Q≥240





SW4
M_D=5 Nm !




SW13
M_D=25 Nm




2x
T20
M_D=1 Nm
2x
T20
M_D=5 Nm



SW13
M_D=25 Nm



T20
M_D=1 Nm



T20
M_D=5 Nm

HQ 2/O, .../T, $b_L > 240$ mm

1) 3 842 549 814

Kein Lieferumfang!

Not included in the scope of delivery!

不在供货范围内!



Pas compris dans la fourniture !

Non compreso nella fornitura!

No incluido en el volumen de suministro.

Não incluído no lote de fornecimento!

3 842 559 608



HQ 2/O, BG II, $b_L = 480$ mm

1) 3 842 549 814

Kein Lieferumfang!

Not included in the scope of delivery!

不在供货范围内!


Pas compris dans la fourniture !

Non compreso nella fornitura!

No incluido en el volumen de suministro.

Não incluído no lote de fornecimento!

3 842 559 609



EQ 2/TR-90, $b_L = 160$ mm**1) 3 842 549 814**

Kein Lieferumfang!

Not included in the scope of delivery!

不在供货范围内!

Pas compris dans la fourniture !

Non compreso nella fornitura!

No incluido en el volumen de suministro.

Não incluído no lote de fornecimento!

2) Vorhandenes Bauteil aus HQ 2/... wieder verwenden.

Reuse existing component from HQ 2/...

重复使用 HQ 2/... 中的现有部件。


Réutiliser le composant disponible de HQ 2/...

Utilizzare nuovamente il componente disponibile da HQ 2/...


Volver a utilizar el componente HQ 2/... existente.

Voltar a utilizar a peça existente do HQ 2/...

HQ 2/...

3 842 559 610


M8x16



G(2x)



H(2x)



3x

