Dosing valves

- The dosing valve defines the quantity of oil which is supplied to the drive module per site in one lubrication impulse

Assembly-Technology, PDF version, 2023-08-223, © Bosch Rexroth AG, subject to change.
Valid edition only on the Internet. Copies of any type are not subject to change.

Delivery notes

Scope of delivery

Set consisting of 2x dosing valves and 2x plug connections pre-fitted for a hose, and 2x straight tube connections
In addition, 2x pivot connections for adapter sets

Ordering codes

	No.
Dosing valve LU 2/V-0.06-D4-1/8	3842562931
Dosing valve LU 2/V-0.10-D4-1/8	3842562932
Dosing valve LU 2/V-0.16-D4-1/8	3842562933
Dosing valve LU 2/V-0.20-D4-1/8	3842562934
Dosing valve LU 2/V-0.30-D4-1/8	3842562935
Dosing valve LU 2/V-0.06-1/8-1/8	3842562936
Dosing valve LU 2/V-0.10-1/8-1/8	3842562937
Dosing valve LU 2/V-0.16-1/8-1/8	3842562938
Dosing valve LU 2/V-0.20-1/8-1/8	3842562939
Dosing valve LU 2/V-0.30-1/8-1/8	3842562940
Dosing valve LU 2/V-0.50-D4-1/8	3842562943
Dosing valve LU 2/V-0.50-1/8-1/8	3842562944
Dosing valve LU 2/V-0.03-D4-1/8	3842562947
Dosing valve LU 2/V-0.03-1/8-1/8	3842562948

Assembly-Technology, PDF version, 2023-08-223, © Bosch Rexroth AG, subject to change.
Valid edition only on the Internet. Copies of any type are not subject to change.