



Armrest




- Armrest
- Adjustable armrest
- Armrest with pad

[PDF](#) Assembly instructions


- Armrest
- Soft support pads protect wrists and arms
- ESD version: Conductive. ESD conductivity can be reduced due to UV rays, heat, wear and chemicals. We therefore recommend a yearly check.
- Adjustable armrest
- Relieves arm strain during assembly work
- Fastened to table frame; suitable for all Rexroth box type workstations
- Armrest with pad
- Relieves arm strain during assembly work
- Hinges allow precisely controlled movements
- Clamp attachment to table top
- ESD version for use at ESD workstations

Dimensions


Armrest



Adjustable armrest



Armrest with pad



Ordering codes

	ESD	No.
Armrest		3842191186
Armrest ESD		3842516704
Adjustable armrest		3842191178
Armrest with pad		3842515493
Armrest with pad ESD		3842515525