Distributor blocks

- The distributor block has room for 2, 4, 6 or 8 dosing valves. Each with an input and output for connecting to other distributor blocks or the pump LU 2/P via a hose or a tube

Assembly-Technology, PDF version, 2023-08-223, © Bosch Rexroth AG, subject to change.
Valid edition only on the Internet. Copies of any type are not subject to change.

Dimensions

Distributor block 2x LU 2/M-2



Distributor block 4x LU 2/M-4



Distributor block 6x LU 2/M-6



Assembly-Technology, PDF version, 2023-08-223, © Bosch Rexroth AG, subject to change.
Valid edition only on the Internet. Copies of any type are not subject to change.

Distributor block 8x LU 2/M-8



Delivery notes

Scope of delivery

Including 2x straight connections for a hose and 2x hose straight tube connections, as well as 1x screw plug
Each including 2 T-nuts and 2 cylinder screws for fastening into a 10x profile slot

Ordering codes

	No.
Distributor block 2x LU 2/M-2	3842562927
Distributor block 4x LU 2/M-4	3842562928
Distributor block 6x LU 2/M-6	3842562929
Distributor block 8x LU 2/M-8	3842562930