

Connection Kits for Transverse Conveyors




- For connecting the modules of the TS 2*plus* on a transverse conveyor laterally (end-to-section)
- Also required: lift transverse unit

Technical data


Use: To connect the TS *2plus* modules on a transverse conveyor laterally (end-to-section)

Also required: Lift transverse unit


	Longitudinal conveyor	
	ST 2/B, SP 2/B, ST 2/B-100, ST 2/C-100, ST 2/R-100	ST 2/C-H, ST 2/R-H, ST 2/R-V
Transverse conveyor		
AS 2/B-150, AS 2/B-	3842518828	–
AS 2/C-100, AS 2/C-	3842528192	3842528192
AS 2/C-400, AS 2/C-	3842518828	3842518828
AS 2/R-300, AS 2/R-	3842528192	3842528192
AS 2/R-1200, AS	3842518828	3842518828
UM 2/B	3842518828	–
UM 2/C-60, UM 2/C-	3842528192	3842528192
BS 2	3842525110	–
BS 2/C (drive side and return side) BS 2/R (drive side)	3842528192	3842528192
BS 2/C-H (drive	3842518828	3842518828
BS 2/C-H	3842528192	3842528192
KU 2 (Antriebs- und	3842528192	3842528192

Delivery notes


BS 2/R, C, HQ2 connection kit



BS 2 connection kit



TS2 mounting kit



Ordering codes

	No.
TS2 mounting kit	3842518828
BS 2/R, C, HQ2 connection kit	3842528192
BS 2 connection kit	3842525110